



EGO REACH / TWIST LOCK NETS MESH BAG REPLACEMENT INSTRUCTIONS

- ① Drive plastic pin out from back side of yoke holding the wire frame
- ② Pull wedge biscuit and wire hoop frame from the top of the yoke
- ③ Pull or cut off old mesh from wire frame
- ④ String new mesh around wire frame starting on one side and working around the frame to the other side.
- ⑤ Insert the wire frame back into the top of yoke
- ⑥ Insert the wedge biscuit back into the yoke ensuring hole in yoke and biscuit align
- ⑦ Drive the pin back into the yoke from front side

HAVE QUESTIONS PLEASE EMAIL US AT: support@egofishing.com **OR GIVE US A CALL AT:** 1-800-698-6841
